IMPORTANT SAFETY INSTRUCTIONS		Preliminary operations	14	
READ CAREFULLY AND KEEP FOR		Using the accessories	14	
FUTURE REFERENCE	3	Display	15	
Recognize safety information General safety instruction		First use	16	
		Using the oven	17	
Appliance purpose	7	Cooking tips	23 24 25	
Proposition 65 Warning	9	Smart Cooking		
Manufacturer's liability	10	History		
Identification plate	10	Mini guide to accessories	25	
Disposal	10	Discover the recipes	25	
To save energy	10	My recipes	25	
DESCRIPTION		Other functions	27	
General description	11	Settings	32	
Control panel	11	CLEANING AND MAINTENANCE	35	
Other parts	11	Cleaning the appliance	35	
Accessories	12	Cleaning the oven cavity		
SE 13		Cleaning the top section		
Microwaves		Cleaning the door	36	
14 IICI O 44 C 4 C 3	13	Extraordinary maintenance	38	

We recommend that you read this manual carefully. It includes all the instructions on maintaining the esthetic qualities and functionality of the appliance you have purchased. For more information about the product: https://www.smeg.com

IMPORTANT SAFETY INSTRUCTIONS READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

WARNING: If the instructions contained in this manual are not followed precisely, fire or explosion may result causing property damage, personal injury or death.

OWNER: Please retain these instructions for future reference and pass them on to any future user.

IMPORTANT: Save these instructions for the local electrical inspector's use.

NOTICE: This appliance must be installed solely and exclusively by a qualified technician. Any technical procedures must be carried out by an authorized technician.

READ AND SAVE THESE INSTRUCTIONS

Recognize safety information

The safety messages will inform you of

potential hazards, how to avoid the risk of injury and what can occur if the instructions

are not followed.



WARNING

 This indicates that death or serious injuries may occur as a result of nonobservance of this warning.



CAUTION

 This indicates that minor or moderate injuries may occur as a result of nonobservance of this warning.



NOTES

 This indicates important information and/or suggestion.

General safety instruction



CAUTION

- This appliance is NOT designed for installation in manufactured (mobile) homes, on a boat or in recreational vehicles (RVs).
- DO NOT install this appliance outdoors.
- This unit is designed as a cooking appliance. For safety purposes, never use it for warming the room or as a space heater.



WARNING

- Never allow children to play with packaging material.
- DO NOT modify or alter the construction of the appliance.
- Do not store or use gasoline or other flammable vapors, liquids or materials near this or any other appliance.
- Do not step, lean or sit on the door appliance, it can result in serious injuries and cause damage to the appliance.
- Make sure your appliance is properly installed and grounded by a qualified technician. Installation, electrical connections and grounding must comply with all applicable codes.

Injury to persons



WARNING

- This appliance complies with current safety regulations. Improper use of this appliance can lead to personal injury and property damage
- During use, the appliance and its accessible parts become very hot. Small children must be kept away from the appliance.
- Do not touch the inside of the device.
 During use the appliance and its accessible parts become very hot even if they remain dark in color. The oven cavity can be hot enough to cause burns.
- To reduce the risk of fire, electric shock, personal injury or damage when using the device, follow these safety precautions:
- During and after use, do not touch the inner areas of the oven cavity until they have had sufficient time to cool.
- Do not allow clothing or any flammable material to come in contact with hot surfaces. If personal clothing or hair catch fire, roll on the ground to extinguish the flames.
- Tie up hair to prevent it from catching fire
- WEAR APPROPRIATE CLOTHING: Never wear loose or dangling clothing when using the appliance.
- During and immediately after use, do not hang or place objects on any part of the appliance.
- Protect your hands by wearing oven gloves when moving food inside the oven.
- Use only dry potholders: wet potholders on hot surfaces can cause steam burns.
 Do not let the potholder touch hot heating elements. Do not use towels or other bulky cloths.
- Never attempt to extinguish flames/fire with water. Turn off the appliance and cover the flame with a lid or a fire

- blanket, or use dry chemicals or foam fire-extinguishers. Alternatively, use sodium bicarbonate.
- Make sure to have foam fireextinguishers close to the appliance.
- Use a fire extinguisher ONLY if it is Class ABC, you know how to use it, the fire is small and contained near the appliance, the fire department has already been alerted and you can fight the fire keeping your back to the exit.
- It is important for your safety to install a smoke detector near the kitchen.
- This appliance may be used by children and by persons with reduced physical, sensory or mental capacity, or without sufficient experience or knowledge, provided that they are supervised or instructed by adults who are responsible for their safety.
- Activate the system lock so that children cannot inadvertently turn on the appliance.
- Children's skin is much more sensitive to high temperatures than that of adults. Do not allow children to touch the door glass, control panel and ventilation slots.
- Children should not play with the appliance.
- Keep children away unless they are constantly supervised.
- Do not allow children to approach the appliance when it is in operation.
- Pets should not be near the appliance while it is in operation.
- Cleaning and maintenance should not be performed by children without supervision.
- Before manually cleaning any part of the appliance, make sure all controls are off and the appliance is cool. Cleaning the hot appliance can cause burns.
- Cooking process should always be kept under control. A short cooking process must be continuously surveyed.
- Never leave the appliance unattended during cooking operations where fats or


- oils could overheat and take fire. Be very careful.
- Do not leave food in the appliance for a long period of time, this may cause food poisoning or illness.
 - Do not introduce sealed cans for canning or reheating food. Risk of injury caused by increased pressure.
- Risk of injury caused by food.
- Do not touch a red-hot pan, risk of burns.
- Do not pour water directly on very hot trays.
- Keep the door closed while cooking or baking.
- If you need to move food or at the end of cooking, open the door 1" 15/16 (50 mm) for a few seconds, let the steam come out, then open it fully.
- Do not insert sharp metal objects (knives and utensils) into the slots.
- Turn off the appliance after use.
- Risk of injury from electric shock.
- DO NOT USE OR STORE FLAMMABLE MATERIALS INSIDE OR NEAR THE APPLIANCE.
- DO NOT USE AEROSOLS IN THE VICINITY OF THIS APPLIANCE WHILST IT IS IN USE.
- DO NOT MODIFY THIS APPLIANCE.
- Do not pull the cable to remove the plug.
- Damage to the device may compromise your safety; do not use it if damaged.
- DO NOT USE THE APPLIANCE if the door is warped, if door hinges are loose, if abnormal holes or cracks are visible, and if the power cord is damaged.


Damage to the appliance



 Do not use abrasive or corrosive detergents (e.g. scouring powders, stain removers and metallic sponges), rough or abrasive materials or sharp metal scrapers on glass parts as this could scratch the surface and break the glass. If possible, use wooden or plastic utensils.

- Do not sit on the appliance.
- Do not use cleaning products containing chlorine, ammonia or bleach on the steel parts or those with metallic surface finishes (e.g. anodizing, nickel or chrome plating).
- Racks and trays should be inserted as far as they will go into the side guides. The mechanical safety locks that prevent them from being removed must face downwards and towards the back of the oven cavity.





- Always place racks and trays in the desired position while the oven cavity is cold. If it is necessary to move racks and trays while the oven cavity is hot, take care that the potholder does not come in contact with the heating element.
- Do not use steam jets to clean the appliance.
- Do not use any spray products near the appliance.
- DO NOT USE FLAMMABLE PRODUCTS FOR CLEANING THE APPLIANCE.
- Do not clean, scrub, damage or remove the seal, which is essential for a good, airtight seal during cooking. Replace the seal if it is damaged or encrusted with food residue.
- Do not block openings, ventilation slots and heat dissipation vents. Covering the ventilation vents may cause the appliance to overheat.
- Fire hazard: never leave objects in the oven cavity.
- DO NOT USE THE APPLIANCE TO HEAT ROOMS FOR ANY REASON.
- Do not use this appliance as storage

- space.
- Do not use plastic dishes or containers for cooking or baking food.
- Do not place sealed tins or containers in the oven cavity.
- Remove all trays and racks which are not required during cooking.
- DO NOT COVER ANY PART OF THE APPLIANCE WITH ALUMINUM OR TIN FOIL SHEETS. The use of aluminum covering may cause electric shock or fire hazard or obstruct the flow of heat and air. The foil is an excellent thermal insulator because it allows heat to be trapped underneath it. This can interfere with cooking and damage the enamel of the oven cavity.
- Prevent the aluminum foil from coming into contact with the heating elements.
- Do not place pots or pans directly on the bottom of the oven.
- If necessary, you can use the tray rack (supplied or sold separately, depending on the model) by placing it on the bottom as a support for cooking.
- If you wish to use greaseproof paper, place it so that it will not interfere with the hot air circulation inside the oven cavity.
- Be careful of spilling food with high sugar and acid content (fruit juices, cakes, tomatoes, milk, etc.), this may cause discoloration of enamel.
 Discoloration does not change the properties of the enamel; do not attempt to remove these stains.
- Be careful when cooking foods with high alcohol content (rum, brandy, bourbon, etc...). The alcohol content in food is highly flammable and can damage the oven cavity.
- Do not use the open door to place pans or trays on the internal glazing pane.
- Do not use the open door as a lever to move the appliance into place.
- Do not apply excessive pressure to the door when it is open.
- Do not use the handle to lift or move this

appliance.



NOTES

WHEN FIRST USING THIS APPLIANCE, FOLLOW THESE INSTRUCTIONS CAREFULLY:

- Set a cooking time of at least one hour.
- Heat the empty oven compartment at the maximum temperature to burn off any residues left by the manufacturing process.
- Cold temperatures can damage electronics. When using the appliance for the first time or when it has not been used for a long period of time, make sure that the appliance has been left in an environment with a temperature above 32°F/0°C for at least three hours before turning it on.

WHEN HEATING THE APPLIANCE:

- air the room:
- don't stay.
- If the appliance is built-in behind a cabinet door, do not close the door while it is in use. Closing the cabinet door may cause damage to the appliance, leave the cabinet door open until the appliance has cooled down completely.
- Do not attempt to use the appliance during a power failure.



CAUTION

- In hot and humid environments, there is a greater likelihood of infestation given by pests, and this could damage the appliance. Make sure to keep the appliance clean at all times. Damage caused by pests is not covered by the warranty.
- Make sure that the appliance has been switched off and disconnected from the mains power supply or that the mains power has been switched off before replacing the interior lighting bulbs.

Appliance purpose



CAUTION

This appliance is intended to be used in household and similar applications such

- In kitchen areas provided for employees in shops, offices and other work environments.
- In farms/farmhouses.
- By guests in hotels, motels and other types of residential environments.
- In bed and breakfasts.

For this appliance



CAUTION

- Do not lean or sit on the door when it is open.
- Make sure that no objects are stuck in the doors.
- Do not install/use the appliance outdoors.
- (on some models only) Only use the temperature probe provided or recommended by the manufacturer.
- This appliance can be used up to a maximum altitude of 4000 meters above sea level.
- The bulbs used in this appliance are specific for household appliances; do not use them for home lighting.

Installation and maintenance



WARNING

- Ask the installer to show the circuit breaker and fuse to prevent damage to people or the appliance during future maintenance.
- This appliance must be correctly installed and grounded by a qualified technician.
- Refer to the installation manual for further details
- Do not repair or replace any part of the appliance unless specified in this

manual.

- Before replacing the bulbs inside the oven cavity, it is necessary to turn off the general power supply.
- The bulb guards are made of glass; handle them carefully to prevent them from breaking. Risk of injury.
- Make sure the appliance is not hot while the bulbs are being replaced.
- The appliance door is heavy, use both hands to remove it.
- The appliance door is made of glass elements, handle with care to avoid breakage. Risk of injury.
- Do not grip the appliance door by the handle but only by the side, failure to grip the door properly may result in injury.
- Do not force the appliance door open or closed. The hinges could be damaged and cause damage and injury.
- Do not rest the appliance door on pointed objects, this may cause the glass to break.
- Do not use this device if it is not working properly or if it has been damaged. In such a case, contact customer service.

For microwave appliances

- CAUTION: If the door or the door seal is damaged, the appliance must not be used until it has been repaired by a qualified person.
- CAUTION: It is hazardous for anyone other than a competent person to carry out any service or repair operation which involves the removal of a cover which offers protection against exposure to microwave energy.
- CAUTION: Liquids and other foods must not be heated in sealed containers since they are liable to explode.
- CAUTION: When a combined function is used, children should use the appliance only when supervised by an adult, as very high temperatures are generated.
- When heating food in plastic or paper

containers, keep an eye on the oven due to the possibility of ignition.

NARNING





- When using the microwave to heat or reheat liquids, the boiling process may be delayed – boiling temperature can be reached without the formation of the usual "rolling boil".
- This delayed boiling and consequent superheating of the liquid can generate an explosion inside the appliance, or sudden boiling over of the superheated liquid can occur when removing the container from the appliance.
- To avoid these dangers, it is necessary to insert the supplied boiling rod (or a heat-resistant plastic spoon) in the container while heating.
- The microwave oven is intended for heating food and beverages. Drying of food or clothing and heating of warming pads, slippers, sponges, damp cloth and similar may lead to risk of injury, ignition or fire.
- Microwave heating of beverages can cause delayed eruptive boiling, so care must be taken when handling the container.
- Clean the appliance constantly and remove any food residue.
- Failure to clean the oven cavity encourages deterioration of the surface, which could adversely affect the life of the appliance and possibly lead to a dangerous situation.
- The appliance shall not be cleaned with

- a steam cleaner
- Do not use the microwave to dry food.
- Do not use the microwave to heat oils or fry.
- Do not use the appliance to heat foods or beverages containing alcohol.
- Do not heat eggs in their shells or whole hard boiled eggs; they may explode even after the heating process has completed.
- Do not heat food contained in food packages.
- Do not use the combination functions to heat or boil liquids.
- Baby food should not be heated in sealed containers. Remove the cover or the teat (in the case of baby bottles). Always check the temperature of the preparation after it has been heated, it should not be too high. The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.
- Puncture the skin of food that has a hard skin or peel (e.g. potatoes, apples, etc.) before cooking.
- Do not use the microwave functions when the oven is empty.
- Use kitchenware and utensils that are suitable for use in a microwave oven.
- Do not use aluminium containers to cook food.
- Metallic containers for food and beverages are not allowed during microwave cooking.
- Do not use dishes with metallic decorations (gold-plated or silver).
- If present, do not use the tray and/or deep tray for microwave cooking ONLY.
- If smoke is present, switch off or unplug the appliance from the power socket and keep the door closed to smother any flames.
- This appliance complies with the current standards and directives regarding safety and electromagnetic compatibility. However, it is recommended that people who wear

- pacemakers maintain a minimum distance of 20-30 cm between the pacemaker and the microwave oven when it is in operation. Contact the pacemaker manufacturer for further information.
- The appliance operates in the 2.4GHz ISM band.
- In compliance with the provisions regarding electromagnetic compatibility, the appliance belongs to group 2 and class B (EN 55011).

WARNING





- When using the microwave, the food (or its container) must not be placed on the bottom of the oven cavity. Use the supplied accessories inserted in the shelves suitable for the recipe you want to make.
- DO NOT USE CONTAINERS/ ACCESSORIES (trays, glass dishes, etc.) RESTING DIRECTLY ON THE BOTTOM OF THE OVEN CAVITY.
- If the appliance is installed in a cabinet, it must be operated with any cabinet door open.

Proposition 65 Warning

This product may contain a chemical known to the State of California, which can cause cancer or reproductive harm. Therefore, the packaging of your product may bear the

following label as required by California:

WARNING

WAKINING State of California propositions 65 Warning

Cancer or Reproductive Harm

More informations:

www.P65Warnings.ca.gov

Manufacturer's liability

The manufacturer accepts no liability for damage to persons or property caused by:

- use of the appliance in any way other than stipulated herein;
- failure to comply with the instructions in the User Manual:
- tampering with any part of the appliance;
- use of after-market replacement parts.

Identification plate

- The identification plate contains model, technical data, serial number and brand name of the appliance.
- It is the responsibility of the installer to comply with the installation information specified on the identification plate.
- Identification plates are visibly placed on the back of the appliance or on the frame of the oven cavity.
- THE IDENTIFICATION PLATE SHOULD NEVER BE REMOVED.

Disposal



WARNING

Entrapment risk for children. Before you throw away an old appliance:

- Remove the doors.
- Leave the racks and the trays positioned so that children cannot easily climb inside.
- Do not leave the packaging or any parts of it unattended.
- Destroy or recycle cardboard, plastic bags, and any outer packaging material immediately after unpacking the appliance. Children should NEVER

use these items for play. They can cause suffocation and death

CAUTION

Take the appliance to a suitable recycling center for electric and electronic waste, or return it to the dealer when purchasing an equivalent product, as a one-on-one exchange.

Before you throw away an old appliance:

- Unplug the power cord plug.
- Cut the power cord.
- Do not allow children to climb, stand on, or attach themselves to the appliance's racks and trays.
- Do not allow children to play with the appliance.


To save energy (😕

It is highly recommended to follow the recommendations below to reduce energy consumption.

- Only preheat the appliance if the recipe requires you to do so.
- In all functions, avoid opening the door during cooking.
- Unless otherwise indicated on the packaging, defrost the frozen food before placing it in the oven cavity.
- In case of multiple cooking, it is advisable to cook the products one after the other to make the most of the already hot oven cavity.
- It is preferable to use dark metal pans, which help to absorb the heat better.
- Remove all trays and racks which are not required during cooking.
- Turn off the oven a few minutes before the time required. Cooking will continue for the remaining minutes with the heat already accumulated inside the oven.
- Do not open the oven door very often to avoid heat loss.
- Keep the inside of the oven clean at all times.

DESCRIPTION


General description



- 1 Control panel
- 2 Gasket
- 3 Light bulb

- 4 Fan
- 5 Door
- 1,2,3... Frame shelf

Control panel



1 ON/OFF button

The ON/OFF button turns the appliance on or off.

2 Display

The touchscreen display allows you to interact with the appliance. Touch the icons to access the various functions. All the operating parameters will be shown on the display.

Other parts

Positioning shelves

The appliance has shelves for positioning trays and racks at various heights. The insertion

91477B246/A DESCRIPTION - 11

heights are indicated from the bottom upwards.



NOTES

Any telescopic rails can be hooked up to the fifth shelf from below. The sixth shelf does not allow the rails to be hooked

Coolina fan

The fan cools the appliance and comes into operation during cooking.

The fan causes a steady outflow of air from above the door which may continue for a short period of time even after the appliance has been turned off

Oven cavity lighting

The internal lighting for the appliance turns on:

- when the door is opened;
- during one function, touch the light symbol to manually activate or deactivate the

oven cavity light, apart from the Manager and





functions.




In order to save energy, the light turns off after about one minute from the start of cooking or whenever the door is opened (this function can be disabled via the secondary menul

Accessories


- Not all accessories are provided on all models
- Accessories that may come into contact with food are made of materials that comply with all legal provisions in force.
- Original accessories supplied or optional can be purchased at authorized service centers. Only use original manufacturer's accessories

Deep tray




Useful for collecting fat from foods placed on the rack above and for cooking pies, pizzas, baked desserts, biscuits, etc.

Rack




Useful to hold cookware with food to be cooked

Glass tray



Useful for any type of cooking and collecting fat from foods placed on the rack above. To be placed on top of the lowered pan stand, it is particularly suitable for microwave cooking.

Boiling rod




To be placed in containers when heating liquids, necessary to avoid delayed boiling.

12 - DESCRIPTION 91477B246/A


Optional accessories (can be purchased separately)

PPR2 or STONE (refractory stone)



Ideal accessory for baking bread (pizza, bread, focaccia...), but you can also use it for more delicate preparations such as biscuits.


BBQ (teflon-coated barbecue grill pan)



Double-use accessory: the ridged side is recommended for grilling meat (fillets,

hamburgers...), while the smooth surface can be used for cooking vegetables, fruit, fish...

AIRFRY (oil-free frying grill)



Recommended accessory for air-frying previously breaded, precooked and/or frozen food (fries, potato or meat croquettes, small mozzarella bites...).

USE

Microwaves

generation of heat.

The appliance is equipped with a microwave generator called a magnetron. The microwaves generated are evenly emitted into the oven cavity in order to reach the food and heat it. Heating takes place through friction between the molecules contained in the food (mainly

The heat generated directly inside the food allows it to be defrosted, re-heated or cooked in a shorter time compared to traditional cooking.

water molecules), with the consequent

Using containers suitable for microwave cooking allows the microwaves to reach the food in a uniform manner.

Materials suitable for use with microwaves

In general, in order for all of the food to be reached, the materials used for microwave cooking must be transparent to microwave energy.

Below is a table of materials to use and those not to use:

MATERIALS TO USE:

- Glass (always remove lids)*
- Baking ware
- Glasses
- lars
- Porcelain
- Earthenware
- Plastic (only where suitable for microwave use)*
- Containers
- Plastic wrap (must not come into contact with the food)
- *only if heat-resistant.

MATERIALS NOT TO BE USED

- Metals (can lead to arcing or sparks)
- Aluminum foil
- Aluminum trays
- Plates
- Metal utensils
- Freezer bags tie wraps
- Wood
- Crystal glasses

91*477*B246/A

- Paper (risk of fire)
- Polystyrene containers (danger of contamination of foodstuffs)



- Dishes must be free of metal decorations.
- Do not use metal accessory trays in the microwave or combined microwave functions

Testing dishes



NOTES

 The microwave function can be used without any food inside the oven only for this test.

To check whether the cookware is suitable for use with microwave cooking, carry out this simple test:

- 1. Remove all accessories from the oven cavity.
- 2. Place the cookware to be tested on the rack inserted in the first shelf.
- 3. Select the microwave function at maximum power level (e.g. 1000 W).
- 4. Set a cooking time of 30 seconds.
- 5. Start cooking.



WARNING

 Stop the test immediately if there is a cracking sound or if sparks are emitted from the cookware. If this happens, it means that the cookware is not suitable for microwave cooking.

At the end of the test the cookware must be either cold or slightly warm. If the cookware is hot then it should be considered as unsuitable for microwave use.

Preliminary operations



WARNING

- Remove all protective film from the outside and inside of the appliance and accessories.
- Remove any labels (apart from the technical data plate) from the accessories and shelves
- Remove and wash all the appliance accessories (see chapter "CLEANING

AND MAINTENANCE").

First heating

- Set a cooking time of at least one hour (see paragraph "Using the oven").
- Heat the empty oven compartment at the maximum temperature to burn off any residues left by the manufacturing process.

When heating the appliance

- air the room;
- don't stay.

Using the accessories




WARNING

 Accessories that can be purchased separately (BBQ and STONE), should be placed on the rack. They should not be placed on the bottom of the cooking compartment, risk of damage to the appliance.

Racks and trays

Racks and trays have to be inserted into the side guides until they come to a complete stop.

 The mechanical safety locks that prevent the rack from being removed accidentally must face downwards and towards the back of the oven cavity.





NOTES

- Gently insert racks and trays into the oven until they come to a stop.
- Clean the trays before using them for the first time to remove any residues left by the manufacturing process.

Boiling rod



WARNING


 To avoid the danger of explosion inside the appliance or the sudden boiling over of superheated liquids, always place a boiling rod in the liquid that is being heated.

14 - USE 91477B246/A

 Use the boiling rod only with Microwave functions. The rod must not be used with combination and traditional functions.

When using the microwave to heat or reheat liquids, the boiling process may be delayed. To avoid this, place the boiling rod (or a heat-resistant plastic spoon) supplied into the

container while heating.



Display




The parameters and values for the currently selected function will be indicated on the display. To use it, simply touch the "virtual" buttons and/or scroll through the values shown (the picture shows the main menu screen).

Information area

Information regarding the menus and sub-menus of the functions in progress in the main area are shown in this area.

The following are also present in this area:

- HOME button: touch this button to return to the main menu;
- INFORMATION button: touch this button to display the following screen:



current time display.

2 Main area

The various functions of the appliance can be set in this area. Touch the buttons and values to set the required function.

3 Lower area

There are various shortcut function buttons in this area, which vary according to the functions set in the main area:



MY RECIPES

□ LIGHT

settings

According to the page that is displayed, the following buttons may also be present:

BACK

91477B246/A USE - 15

CONFIRM

START

REPLAY



SAVE



RAPID PREHEATING



<u></u> NOTES

 Press and hold the HOME button or the ON-OFF button for a few seconds to stop cooking immediately at any time and return to the main menu.

First use



 The following instructions are also valid in the case of a prolonged power failure.

To switch the appliance on:

1. Connect the appliance to the mains power supply.

The manufacturer's logo will display for a few seconds.




 After the appliance is switched on, you will need to wait a few seconds before you can use it.

Next, the display shows the setting screen for the current time.

To be able to start any cooking function, the current time must be set.

2. Scroll up and down through the hours and minutes to set the current time.



Touch the CONFIRM button (at the right in the lower area 3) to set the current time.



- To change the current time (e.g. due to summer/winter time), touch the time shown on the display (located in the information area
 on the right).
- The current time can also be set or modified by touching the time indicated on the display for at least 3 seconds.

When first used, the appliance may be set to a different language from yours. It is recommended that you set the required language at this point.

- Touch the SETTINGS button on the display (at the right in the lower area 3).
- 5. Touch the display 5. button.
- 6. In the Language option (on the left), scroll through the available languages (on the right) to select the required language.
- 7. Touch the CONFIRM button.

Deactivating the display



 When the "Show the time" mode is set to Off, if the time display is shown, the display will switch off automatically after 2 minutes.

To deactivate the display manually:

16 - USE 91477B246/A

• Press and hold the ON-OFF (1) button for a few seconds until you hear a sound.

Reactivating the display

To reactivate the display when it is off:

Press and hold the ON-OFF (1) button for a few seconds until you hear a series of sounds

The display turns on after a few seconds. The display shows the main menu when it is switched on again.



In some cases, the ON-OFF (1) button does not deactivate the display. For example, when:

- There is a cooking function in progress (the button stops the function);
- The door is open;
- A minute minder timer is active:
- the Show Room and/or DEMO Demo modes are active.

Using the oven



Microwave cooking




Given that they penetrate directly into the food, microwaves allow cooking to take place in a very short period of time and with a considerable saving of energy. They are suitable for cooking without fat and also for defrosting and re-heating food while maintaining its original appearance and fragrance.

1 Place the food inside the oven



When cooking using the microwave function only, the appliance does not perform preheating. The food can be placed immediately inside the appliance. 2. Touch the time indicated on the display.




3. Touch the COOKING



button on the

"main menu" (in the main area 2).




MICROWAVE



5. Touch the MICROWAVE POWER button or the relative value.

6. Scroll through the values and select the required power level of the microwave.




NOTES

- The power level of the microwave is from 100 W to 1000 W.
- 7. Touch the CONFIRM 🗸 button (at the lower right (3) to confirm the new cooking temperature that has been selected.
- 8. Touch the COOKING DURATION 💍 button or the relevant value.



9. Scroll through the values and select the required duration.



10. Touch the CONFIRM button to confirm the selected cooking duration.



- The hours and minutes can be selected separately.
- The duration of the steam cooking can be from a minimum of 5 seconds to a maximum of 29 minutes and 55 seconds.
- 11. Touch the START button to start microwave cooking.



 Each time the door is opened, the function in progress stops and the message "Do you want to interrupt the function" displays. To continue the function press NO, to stop the function press YES and close the door.

End of microwave cooking

At the end of cooking, "Function ended" displays and a buzzer sounds briefly.



 Touch the HOME button to exit from the function.

Microwave power levels

Below is a list of the power levels that can be

selected:

Power (W)	Uses	
100	Thawing food	
200		
300		
400	Cooking meat or delicate cooking	
500		
600	Re-heating and cooking food	
700		
800		
900	Heating liquids	
1000		

Combination cooking with microwave



Combination cooking is a mix of traditional cooking and microwave operation. These functions are marked by the microwave function icon and the symbol of a traditional function switching on.


Touch the COOKING
"main menu".

"main menu".



button on the


- Select a combination function (for example SPEED CONV. BAKE + relevant cooking screen.
- 3. Touch the TEMPERATURE button or the relevant value.
- 4. Scroll through the values and select the required cooking temperature.



- 5. Touch the CONFIRM button (at the lower right 3) to confirm the new cooking temperature that has been selected.
- 6. Touch the MICROWAVE POWER button or the relative value.


18 - USE 91477B246/A

Scroll through the values and select the required power level of the microwave.





- The power level of the microwave is from 100 W to 700 W
- 8. Touch the CONFIRM button to confirm the selected microwave intensity.
- 9. Touch the COOKING DURATION button or the relevant value.
- 10. Scroll through the values and select the required duration.



NOTES

- The hours and minutes can be selected separately.
- The duration of the combined microwave cooking can be from a minimum of 1 minute to a maximum of 12 hours and 59 minutes.
- 11. Touch the CONFIRM button to confirm the selected cooking duration.
- 12. Touch the START button (at the lower right 3) to start the microwave combined cooking.

Pre-heating stage

Combination cooking is always preceded by the pre-heating stage that allows the oven cavity to heat up to the set cooking temperature.


This stage is indicated by a progressive increase in the temperature level reached.



MOTES

- Unless otherwise indicated in the recipe, it is not recommended to place food in the oven during the preheating stage.
- You can skip the pre-heating stage touching the dedicated button

At the end of preheating the temperature reaches the maximum set level. A buzzer sounds and a message appears on the display to indicate that cooking starts automatically.



- Open the door
- 2. Place the food inside the oven.
- 3. Close the door.
- 4. Touch the CONFIRM button to start cooking.

End of combination cooking

At the end of cooking, "Function ended" displays and a buzzer sounds briefly.

List of combined cooking functions

SPEED CONVECTION ROAST



The addition of microwaves speeds up traditional cooking. Ideal for biscuits, cakes and cooking on more than one level.

SPEED CONVECTION BAKE SPEED BROIL



The addition of microwaves speeds up traditional cooking. Suitable for all dishes, allows you to cook on multiple levels without mixing smells and flavors.

91477B246/A USE - 19



Microwaves allow quicker cooking and the grill creates perfect browning

Traditional cooking



Each time the door is opened, the function in progress will stop and then automatically restart when the door is closed again.

1. Touch the time indicated on the display.



2. Touch the COOKING



button on the

"main menu" (in the main area 2).



3. Select a desired function (such as TRUE

CONVECTION () to enter the relevant cooking screen.

4. Touch the START button (at the lower right (3) to start pre-heating.

Pre-heating stage

Cooking itself is preceded by a preheating stage, which allows the appliance to heat to the cooking temperature more quickly.

This stage is indicated by a progressive increase in the temperature level reached.





Unless otherwise indicated in the recipe, it is not recommended to place food in the oven during the preheating stage.



You can skip the pre-heating stage touching the dedicated button

After pre-heating, a buzzer will sound and a message will appear on the display to indicate that the dish can be put in the oven cavity.



Cooking phase

- 5. Open the door
- 6. Place the dish with the food to be cooked into the oven cavity.
- Close the door.
- 8. Touch the CONFIRM 🗸 button to start cooking.

This step is indicated by this wording: "FUNCTION IN PROGRESS".



NOTES

Once cooking has started, it is possible to set timed cooking:

Touch the TIME X button and follow the instructions in the "timed cooking" section.

Modifying the cooking temperature



NOTES

- The temperature can be modified at any time during cooking.
- 1. Touch the TEMPERATURE button or the relevant value.
- 2. Scroll through the values and select the required cooking temperature.



20 - USE 91477B246/A 3. Touch the CONFIRM button (at the lower right 3) to confirm the new cooking temperature that has been selected.

End of cooking

To end cooking at any time:

1. Touch the STOP button

Timed cooking



NOTES

- Timed cooking is the function which allows a cooking operation to be started and then ended after a specific length of time set by the user.
- 1. After selecting a function, touch the TIME button or the related value.
- Scroll through the values and select the required duration.



 Touch the CONFIRM button to confirm the selected cooking duration.



NOTES

- The hours and minutes can be selected separately.
- The duration of the timed cooking can be from a minimum of 1 minute to a maximum of 12 hours and 59 minutes.

The time expected for the end of cooking

displays under the duration.



- The countdown starts after the pre-heating has ended or if you wish to skip pre-heating (touch the relevant button).
- The minutes required for pre-heating are already included in the end-of-cooking time
- 4. Touch the CONFIRM button to start timed cooking.

This stage is indicated by a progressive increase in cooking.




Delayed cooking



NOTES

- For safety reasons, it is not possible to set the end of cooking time by itself without setting the cooking duration.
- Delayed cooking is the function which allows a time-controlled cooking operation to be stopped at an established time depending on the time set by the user, after which the appliance will switch off automatically.
- After setting timed cooking, touch the DELAYED COOKING button or the relevant value.
- 2. Scroll through the values and select the required end of cooking time.





The hours and minutes can be selected separately.

91477B246/A USE - 21

3. Touch the CONFIRM 🗸 button to confirm the selected end of cooking time.

This stage is indicated by a progressive increase in cooking.



End of cooking

At the end of cooking, "Function ended" displays and a buzzer sounds briefly.



the function. List of traditional cooking functions



- Not all functions are available on some models.
- In the "PIZZA" cooking function, the temperature probe cannot be used.

BAKF



Traditional cooking, ideal for preparing a single dish. For example cooking roast meats, fatty meats, bread, pies.

CONVECTION BAKE



Intense and uniform cooking. Ideal for biscuits, cakes and cooking on more than one level

TRUE CONVECTION



The heat is distributed quickly and uniformly. Suitable for all dishes, ideal for cooking on multiple levels without mixing smells or flavors.

CONVECTION ROAST



Allows quick cooking on multiple shelves without mixing the aromas. Perfect for large volumes that call for intense cooking.

BROIL



Produces excellent grilling and browning results. When used at the end of cooking, gives a uniform browning to dishes

CONVECTION BROIL



Allows optimal grilling, even for thick slices of meat. Perfect for large cuts of

WARM



The heat comes from the bottom of the cavity only. Perfect for cakes, pies, tarts and pizzas.

EUROPEAN BAKE+



Allows you to quickly finish cooking food that is already cooked on the surface but not internally. Ideal for auiches, suitable for all kinds of dishes.

PI77A



Function designed for cooking pizza. Perfect not just for pizzas, but also for biscuits and cakes.

Minute minder timer



NOTES


- This function only activates the buzzer, without stopping the function in progress.
- The Timer can be set from a minimum of 1 minute to a maximum of 12 hours and 59 minutes.
- 1. Touch the TIMER \(\int\) button (in the lower area (3) to access the Timer menu.

Up to 2 minute minder Timers can be set:

2. Touch the button of the TIMER 1 - 12 that you intend to use.



3. Scroll through the values and select the required duration.



22 - USE 91477B246/A 4. Touch the CONFIRM button to confirm the selected duration.



NOTES

- The BASKET button displays in the lower area that can be used to delete a timer if it has been selected.
- 5. Repeat the procedure for the other Timers that you intend to use.
- When finished, touch the CONFIRM button again to confirm the selected timers.



NOTES

- To cancel the operation, touch the RETURN button
- The counter must be set to zero in order to remove the minute minder timer.
- The display cannot be switched off using the ON-OFF button when a timer is active.
- It is not possible to set delay cooking when the temperature probe is used.

In the following display, the TIMER button ON, indicates that one or more minute minder timers have been activated.

Wait for the buzzer to indicate that the time has finished.

Cooking tips

General advice

- Increasing the temperature does not shorten cooking or baking times (the food could be well cooked on the outside and undercooked on the inside).
- Use a fan-assisted function to achieve consistent cooking at several levels.
- To prevent condensation from forming on the glass, hot food should not be left inside the oven for too long after cooking.

Tips for cooking meat

- Cooking times vary depending on the thickness and quality of the meat, and on consumer tastes
- Turn the food to brown on both sides.

- Use a meat thermometer when roasting meat, or simply press on the roast with a spoon. If it feels hard, it is ready; otherwise, it needs to roast a bit longer.
- For meat and potatoes, it is recommended to turn and / or mix the food from time to time in order to obtain a uniform browning on all sides.
- For slow cooking, brown the meat in a pan for a few minutes on all sides before cooking in the oven.
- Microwave cooking is recommended for meat without layers of fat or nerve tissue on the surface.
- For meat roasts with combined microwave functions, it is recommended to turn the food so that it is evenly cooked and browned.

Advice for cooking with the Grill and the Fan with grill

- Meat can be grilled even when it is put into the cold oven or into the preheated oven if you wish to change the effect of the cooking.
- We recommend placing the food at the center of the rack.
- With the Grill function, we recommend that you set the temperature to the maximum value to optimize cooking.

Tips for baking cakes and cookies

- It is preferable to use dark metal pans, which help to absorb the heat better.
- The temperature and baking duration depend on the quality and consistency of the dough.
- To check whether the cake is baked through, stick a toothpick into its highest point at the end of the baking time. If the dough does not stick to the toothpick, the cake is baked.
- If the cake goes flat when it comes out of the oven, on the next occasion reduce the set temperature by about 10°C, selecting a longer baking time if necessary.

Advice for cooking on two shelves:

- It is recommended to have 2 racks (can be requested to Authorized Assistance Centers).
- To facilitate the flow of air, place the molds/ pans in the center of the racks and make sure that their width/diameter does not exceed 11" 13/16 (300 mm).
- Position the racks keeping an empty level

91477B246/A USE - 23

between them.

- Depending on the food and the increased load inside the cavity, cooking on two levels may take a few minutes longer than on a single shelf.
- The functions indicated for cooking on two shelves are TRUE CONVECTION and EUROPEAN BAKE +.

Tips for defrosting and proving

- Place frozen foods without their packaging in a lidless container on the first shelf of the oven
- Do not overlap foods.
- To defrost meat, use a rack placed on the second level and a tray placed on the first level. This way, the liquid from the defrosting food drains away from the food.
- The most delicate parts can be covered with aluminum foil.
- For successful proving, a container of water should be placed in the bottom of the oven.

To save energy

- Turn off the oven a few minutes before the time required. Cooking will continue for the remaining minutes with the heat already accumulated inside the oven.
- Do not open the oven door very often to avoid heat loss.
- Always keep the inside of the appliance clean.

Smart Cooking

This mode allows you to select a previously stored program for cooking food. The appliance automatically calculates the optimum cooking parameters based on the weight selected.

1. Touch the SMART COOKING



button on the "main menu" (in the main area 2).

Select the type of dish required from the SMART COOKING menu (for example

"VEGETABLES



3. Select the sub-category of dish to cook (for

example "MIXED VEGETABLES



 Scroll through the values to set the weight of the food to be to cook.



 Touch the CONFIRM button to confirm the settings.



NOTES

- It is now possible to save the settings as a personal recipe (see section "My recipes").
- 6. Touch the START button to start SMART COOKING.

Cooking will start with the settings specified in the program.



NOTES

 The cooking temperature and duration can be changed at any time, even after cooking has started.

Pre-heating

Cooking is preceded by the pre-heating stage that allows the oven to heat up to the set cooking temperature.

This stage is indicated by a progressive increase in the temperature level reached.



NOTES

 The pre-heating function cannot be disabled when Smart Cooking programs are being used.

After pre-heating, a buzzer will sound and a message will appear on the display to indicate that the food can be put in the oven.

The shelf on which the food should be placed in

24 - USE 91477B246/A

order to obtain best results is also indicated.

Place the food in the oven and confirm

We recommend placing the food
on the fifth shelf from the bottom

- 7. Open the door
- 8. Place the food inside the oven.
- 9. Close the door
- 10. Touch the CONFIRM button to start cooking.

This stage is indicated by a progressive increase in cooking.



End of cooking

At the end of cooking, "Function ended" displays and a buzzer sounds briefly.



11. Touch the HOME button to exit from function. End of cooking.

History

This menu is particularly useful for viewing and reusing the last programs or personal recipes


that were used.

- 1. Touch the HISTORY button on the "main menu" (at the left 3 in the lower area).
- Select the function you wish to reuse and proceed with cooking as described in the previous sections.

Deleting the history

If you wish to delete the history:

- 1. Touch the HISTORY button on the "main menu".
- 2. Touch the BASKET button to delete the history.



3. Touch the CONFIRM button to confirm that you wish to delete the history (or the CANCEL button to cancel the operation).

Mini guide to accessories



We recommend the use of the rack as a support surface for baking molds/casseroles. In the absence of the baking tray rack, the rack can be used as a base for grilling with the

We recommend the use of the deep baking tray for cooking on one level only.

Place the deep baking tray on the center shelf when using the fan-assisted functions. When



using the STATIC function



deep baking tray placed on a shelf below to collect the juices.

, place the deep baking tray on the required shelf.

Place the baking tray on the last shelf with the baking tray grill to cook in GRILL mode





Use the glass dish by placing it on the grid. It is suitable for microwave and combination microwave cooking.

Discover the recipes

To consult the recipes developed for various categories of food and for more information on cooking suggestions, we recommend visiting the dedicated page on the www.smeg.com

website, which can be reached using the QR code on the leaflet supplied with the product.

My recipes

This menu allows you to enter a personal program with the parameters you wish to use.

91477B246/A USE - 25

On first use, the appliance will only offer you to add a new recipe. After saving your recipes, these will then be available in the relevant menu.

1. Touch the MY RECIPES button on the "main menu" (at the left 3 in the lower area).



- It is possible to store a limited number of personal recipes.
- It is not possible to memorize more than 17 recipes that belong to the same category.

Adding a recipe


- 2. Select the type of dish required from the MY RECIPES menu (for example "DESSERTS").
- 3. Touch the NEW RECIPE



- 4. Select the required function.
- 5. Touch the TEMPERATURE button or the relevant value.
- 6. Scroll through the values and select the required cooking temperature.



- 7. Touch the CONFIRM button to confirm the selected cooking temperature.
- 8. Touch the COOKING DURATION button or the relevant value.
- 9. Scroll through the values and select the required duration.



10. Touch the CONFIRM button to confirm the selected cooking duration.

■ NOTES

- The minutes required for preheating are already included in the end-of-cooking time.
- At this point it is possible to add delayed cooking.

Saving a recipe

- 11. Touch the SAVE | button.
- 12. Scroll through the values to set the SHELF.
- 13. Scroll through the values to set the weight of the food to be to cook.



14. Touch the CONFIRM button to confirm the settings.

At this point, a name for the recipe must be entered.


15. Use the alphanumeric keypad to enter the name of the recipe to be saved.



- Use the 123 and buttons to switch from the alphabetic keypad to the numerical keypad and vice versa.
- The recipe name can contain a maximum 12 characters, including spaces.
- The name must contain at least one character in order to store the recipe.
- The character deletes the previous letter.
- To save a recipe, parameters must be set.

26 - USE 91477B246/A

16. Touch the CONFIRM button to store the program.



Starting a personal recipe

- 1. Touch the MY RECIPES button on the "main menu".
- Select the type of dish required from the MY RECIPES menu.
- 3. Select the recipe that was saved previously.
- 4. Touch the START button to start cooking.

Pre-heating

Cooking is preceded by the pre-heating stage that allows the oven to heat up to the set cooking temperature.

This stage is indicated by a progressive increase in the temperature level reached.

This stage is indicated by a progressive increase in the temperature level reached.

After pre-heating, a buzzer will sound and a message will appear on the display to indicate

that the food can be put in the oven.

The shelf on which the food should be placed in order to obtain best results is also indicated.

Place the food in the oven and confirm

We recommend placing the food
on the second shelf from the bottom

- 5. Open the door
- 6. Place the food inside the oven.
- 7. Close the door
- 8. Touch the CONFIRM button to start cooking.

This stage is indicated by a progressive increase

in cooking.

End of cooking

At the end of cooking, "Function ended" appears on the display and a buzzer sounds briefly.

Touch the HOME button to exit from

the function. **Deleting a recipe**

- 1. Touch the MY RECIPES button on the "main menu".
- 2. Select the recipe that was saved previously.
- 3. Touch the DELETE button to delete the recipe.



4. Touch the CONFIRM button to confirm that you wish to delete the selected recipe (or the CANCEL button to cancel the operation).

Other functions

The special functions menu includes several functions such as defrosting, proving or cleaning...

 Touch the OTHER FUNCTIONS button on the "main menu" (in the main area
 2).



Certain functions are not available on all models.

91477B246/A USE - 27

DEFROST BY WEIGHT




Automatic defrosting function. Choose the dish, the oven calculates the time necessary for proper defrosting.



- If the internal temperature is greater than the one required, the function will be stopped immediately and "Internal temperature unsafe, please wait until the oven is cool" will display. Allow the appliance to cool down before activating the function.
- 1. Open the door.
- 2. After weighing the food, place it in the oven cavity.
- 3. Close the door.
- 4. Select DEFROST BY WEIGHT



- Select the type of food to defrost from the categories MEAT - FISH - BREAD -DESSERTS
- Scroll through the values to set the weight of the food to be defrosted.



- Touch the CONFIRM button to confirm the settings.
- 8. Touch the START button to start the defrost by weight function.

When finished, a buzzer sounds briefly, which can be deactivated by touching any point of the display or by opening the door.

Preset parameters:

Туре	•	Weight (oz	Time) (minutes)	
M	eats	17.5	18	
Fis	h	14	25	
Bri	ead	10.5	5	
De	esserts	35	5	



NOTES

- Defrosting times may vary on the basis of the shape and size of the food to be defrosted.
- When defrosting heavy and/or irregularly shaped food (e.g. chicken, fish, etc.), it is advisable to turn it inside the oven cavity at least once by 180°.
- It is not possible to change the default microwave power level (200 W) for the "Defrost by weight" function

DEFROST BY TIME



Manual defrosting function. Select the length of time required for defrosting, when the set time has elapsed, the function will stop.

NOTES

- If the internal temperature is greater than the one required, the function will be stopped immediately and "Internal temperature unsafe, please wait until the oven is cool" will display. Allow the appliance to cool down before activating the function.
- The duration of the "Defrost by time" function can be from a minimum of 1 minute to a maximum of 29 minutes and 55 seconds
- It is not possible to change the default microwave power level (200 W) for the "Defrost by time" function.
- Open the door.
- 2. Place the dish into the oven cavity.

28 - USE 91477B246/A


- 3. Close the door.
- 4. Select DEFROST BY TIME



5. Touch the COOKING DURATION 👸 button or the relevant value.



6. Scroll through the values and select the required duration.



7. Touch the CONFIRM button to confirm the settings.

8. Touch the START button to start the Defrost by time function.


When finished, a buzzer sounds briefly, which can be deactivated by touching any point of the display or by opening the door.

9. Touch the HOME button to exit from the function.

"Turn" procedure

For best defrosting results it is recommended, when necessary, to turn the dish inside the oven


1. Put the dish in the oven placing it parallel to the door



When the appliance displays "Open door and rotate dish or mix ingredients".




Open the door and turn the dish 90°.



NOTES

- If you do not turn the dish, the appliance waits for one minute and then continues defrosting.
- 4. Close the door of the appliance and press the CONFIRM 🗸 button to resume the function.
- 5. If necessary the appliance will again ask for rotation of the dish. The display shows "Open the door and rotate dish or mix ingredients".
- 6. To turn the dish again, you need to open the door and turn the dish by 180°.



Close the door and press the CONFIRM

button to resume the function.

PROOF



This function is particularly suitable for proving dough.

NOTES

- If the internal temperature is greater than the one required, the function will be stopped immediately and "Internal temperature unsafe, please wait until the oven is cool" will display. Allow the appliance to cool down before activating the function.
- For successful Proof, a container of water should be placed in the bottom of the oven.


91477B246/A USE - 29



- It is not possible to modify the default temperature of the Proof function (95°F/ 35°C1
- 1. Open the door
- 2. Position the dough to prove on the second
- 3. Close the door.
- 4. Select PROOF



5. Touch the COOKING DURATION button or the relevant value.





NOTES

- The duration of the Proof function can be from a minimum of 1 minute to a maximum of 12 hours and 59 minutes.
- It is possible to set the delayed function (
- 6. Touch the CONFIRM 🗸 button to confirm the settings.
- 7. Touch the START button to start the proving cycle.


When finished, a buzzer sounds briefly.

PLATE WARMING



Function that heats and keeps plates warm. Position a baking tray on the lowest shelf and put the plates on it to warm.

1. Position the tray on the first shelf and place the plates to be warmed at the center of it.





NOTES

- Do not stack plates too high. Stack plates a maximum of 5/6 high.
- 2. Select PLATE WARMING



3. Touch the START button to start the Plate warming function.



NOTES

Unless otherwise set, the Plate warming function has a maximum duration of 12 hours and 59 minutes

The following can be set while the function is in operation:

- the temperature (from 105°F/40°C to 180°F/80°C);
- the duration of the function 👸



a delayed function (only if a duration different from the detault one is set)

When finished, a buzzer sounds briefly.

KEEP WARM



This function allows you to keep precooked foods warm.

1. Select KEEP WARM



- 2. Touch the TEMPERATURE button or the relevant value.
- 3. Scroll through the values and select the required cooking temperature (from 140°F/60°C to 210°F/100°C).

30 - USE 91477B246/A 4. Touch the START button to start the Keep warm function.

When finished, a buzzer sounds briefly.

STONE



Useful for on stone cooking. For use with the PPR2 or STONE accessory sold separately.



- Please refer to the instructions and recommendations for use described in the accessory documentation.
- 1. Open the door.
- Insert the PPR2 or STONE accessory into the oven cavity (refer to the specific accessory manual).
- 3. Close the door.
- 4. Select STONE.



- Scroll through the values and select the required cooking temperature (from 395°F/200°C to 540°F/280°C).
- 6. Touch the START button to start the Stone function.

MOTES

- As with normal cooking functions, you can skip pre-heating and set a timed and delayed cooking.
- 7. After pre-heating, open the door and place the food to be cooked on the accessory.
- 8. Close the door.

When finished, a buzzer sounds briefly.

BBQ (Barbecue)



Useful for barbecue cooking. For use with the BBQ accessory sold separately.

■ NOTES

- Please refer to the instructions and recommendations for use described in the accessory documentation.
- The temperature probe can be used for the BBQ function (see chapter "Using the temperature probe").
- Open the door.

- 2. Insert the BBQ accessory into the oven cavity.
- 3. Close the door.
- 4. Select BBQ



- Scroll through the values and select the required cooking temperature (from 140°F/60°C to 540°F/280°C).
- 6. Touch the START button to start the BBQ function.

MOTES

- As with normal cooking functions, you can skip pre-heating and set a timed and delayed cooking.
- 7. After pre-heating, open the door and place the food to be cooked on the accessory.
- 8 Close the door

When finished, a buzzer sounds briefly.

AIRFRY



Useful to obtain fried cooking without oil. For use with the AIRFRY accessory sold separately.

MOTES

- Please refer to the instructions and recommendations for use described in the accessory documentation.
- 1. Select AIRFRY



- Turn the temperature knob to select the required temperature (from 395°F/200°C to 540°F/280°C).
- 3. Touch the START button to start the AIRFRY function

■ NOTES

- As with normal cooking functions, you can skip pre-heating and set a timed and delayed cooking.
- When preheating is complete, open the door and insert the AIRFRY accessory with the food to be cooked into the oven cavity.
- 5. Close the door.

When finished, a buzzer sounds briefly.

91477B246/A USE - 31

SABBATH



Function that allows you to cook food whilst respecting the provisions of the Jewish day of rest.



This function results in the appliance operating in a particular way:

- It is possible to set the duration of the Sabbath function.
- The duration of the Sabbath function can be from a minimum of 1 minute to a maximum of 73 hours and 59 minutes.
- No preheating will be performed.
- The cooking temperature that can be selected ranges from 140°F/60°C to 540°F/280°C.
- Oven light disabled, any operation such as opening the door or manual activation will not activate the light.
- The internal fan remains turned off.
- Buzzers disabled.
- Open the door.
- 2. Place the dish into the oven cavity.
- 3. Close the door.
- 4. Select SABBATH



- relevant value. 6. Scroll through the values and select the
- temperature (from 140°F/60°C to 540°F/280°C).



- to confirm 7. Touch the CONFIRM button (the selected temperature.
- 8. Touch the START button to start the Sabbath function

To stop the function:

 Touch the HOME button for around 3 seconds.



Alternatively

Touch the ON-OFF button approximately 3 seconds (the display reverts to the screen of the function).

In the event of a blackout

Following a power failure, the appliance automatically resumes the screen with the Sabbath function requirements. The cooking process is interrupted and cannot be restarted.

Settings



NOTES

In the event of a temporary power cut, all personal settings will remain stored.

The product configuration can be set using this menii

Touch the SETTINGS button on the "main menu" (at the right in the lower area



Language



NOTES

- Allows you to select the language of the display.
- 1. Select Language.
- 2. Scroll through the available languages to select the required language.
- 3. Touch the CONFIRM who button to confirm the selected language.

Controls lock



NOTES

- Allows the appliance to automatically lock the controls after one minute of normal operation without any intervention from the user
- Select (Controls lock.
- 2 Select Yes

32 - USE 91477B246/A 3. Touch the CONFIRM [activate the Controls lock mode.



NOTES

During normal operation, it is indicated by the indicator light turning on in the information area

To temporarily disable the lock during cooking:

4. Touch one of the values that you wish to modify.

A message displays that indicates how to temporarily disable the Controls lock mode.

Press the icon for 3 seconds to deactivate the control lock

5. Touch the (icon for 3 seconds.

Show Room mode (for showrooms only)



NOTES

- This mode deactivates all the appliance's heating elements, while keeping the control panel active.
- During normal operation, it is indicated by indicator light turning on in the information area
- To use the appliance normally, set this mode to Off
- Show Room. Select
- Select On.
- 3. Touch the CONFIRM activate the Show Room mode.

Sound



NOTES

- Whenever one of the display symbols is pressed, the appliance beeps. This setting disables these sounds.
- 1. Select Sound.
- Select Off.

3. Touch the CONFIRM button to disable the sound associated with the touching of the symbols on the display.

Keep warm



NOTES

- This mode allows the appliance to keep cooked food warm (at low temperatures) after cooking finishes with a cooking cycle for which a duration has been set (if this is not manually interrupted), without altering the taste and aromas obtained during cooking.
 - The keep warm function will be activated 5 minutes after cooking has finished; this is indicated by a series of beeps (see cooking or function ended).
- The temperature of the keep warm function is set to 180°F/80°C.
- 1. Select Keep warm.
- 2 Select On
- 3. Touch the CONFIRM activate the Keep warm mode.

Eco light



NOTES

- For greater energy savings, the lights inside the oven cavity are automatically deactivated approximately one minute after the start of cooking or after the door is opened.
- To stop the appliance from automatically deactivating the light after approximately one minute, set this mode to "Off".
- Manual on/off control is always available. Press the symbol, when available, to manually activate the oven light or the symbol to deactivate it.
- The Eco light function is factory set to "On".
- Select Eco light.
- 2. Select On.
- Touch the CONFIRM activate the Eco light mode.

USE - 33 91477B246/A

Digital clock



- Displays the current time in digital format.
- In the event of a temporary power cut, the digital version will remain activated.
- 1. Select Digital clock.
- 2. Select On.

Touch the CONFIRM button to activate the Digital clock mode.



Demo Mode (for showrooms only)



NOTES

- The same as Show Room, when this mode is activated, after a certain period of inactivity, a demonstration of the various screens that illustrate the potential of the appliance is shown on the display.
- To use the appliance normally, set this mode to Off.
- 1. Select DEMO Demo Mode.
- 2. Select On.
- 3. Touch the CONFIRM button to activate the Demo Mode.

Standby time



NOTES

- Turns on/off the clock display when the oven is off.
- The "Display time" function is factory set to Off.
- If the "Display Time" function is set to On, the standby appliance shows the current time in low brightness on the display.
- The "Display Time" function set to On results in higher power consumption of the appliance in standby.
- Select Display Time.
- 2. Select On.

3. Touch the CONFIRM button activate the time display.

Weight type



NOTES

- Allows the unit of measurement to be set to display the weight value in either ounces (oz) or kilograms (kg).
- The Weight type function is factory set to ounces.
- 1. Select kg/ Weight type.
- 2. Select oz or kg.
- Tap the CONFIRM button to activate the desired weight measurement unit.

Clock format



NOTES

- Activates/deactivates the clock display in the 12 or 24 hour format.
- The Clock format function is factory set to 12 h.
- 1. Select 12/24 Clock format.
- 2. Select 12 h or 24 h.
- Touch the CONFIRM button to activate the required clock format.

Temperature format



NOTES

- Allows the temperature scale to be set in either degrees Fahrenheit (°F) or degrees Celsius (°C).
- The Temperature format function is factory set to °F.
- 1. Select % Temperature format.
- 2. Select °F or °C.
- Touch the CONFIRM button to activate the required temperature format.

34 - USE 91477B246/A

Display brightness



- This allows the display brightness level to be selected.
- The Display brightness function is factory set to High.
- 1. Select Display brightness.
- 2. Select from the options High Medium -
- 3. Touch the CONFIRM button to confirm the selection

Restore settings



 This restores all settings to the original factory settings.

4. Touch the FACTORY RESET button on the "settings menu" (at center in the lower area 3).

5. Touch the CONFIRM button to confirm the selection.

CLEANING AND MAINTENANCE

Cleaning the appliance



Surface cleaning

To maintain the surfaces, you must clean them regularly after each use once they have cooled down.

Ordinary daily cleaning

Always use specific products only that do not contain abrasives or chlorine-based acids.

Pour the product onto a damp cloth and wipe the surface, rinse thoroughly and dry with a soft cloth or a microfiber cloth.

Food stains or residues

Do not use steel sponges and sharp scrapers, as they will damage the surfaces.

Use normal, non-abrasive products and a wooden or plastic tool, if necessary. Rinse thoroughly and dry with a soft cloth or a microfiber cloth.

Do not allow residues of sugary foods (such as jam) to set inside the oven. If left to set for too long, they might damage the enamel lining of the oven.

Cleaning the oven cavity

Proper maintenance of the oven's interior requires that it be cleaned regularly, after allowing it to cool.

Avoid leaving dried up food inside the oven because it could damage the enamel surface. Before cleaning, take out all removable parts.

To make cleaning easier, we recommend the removal of:

- The door:
- the frame supports for racks/trays;.



 If you are using specific cleaning products, we recommend operating the appliance at the maximum temperature for about 15-20 minutes to remove any residues.

Drying

Cooking food generates moisture inside the appliance. This is a normal phenomenon and does not affect the appliance's operation in any way.

Each time you finish cooking:


- 1. let the appliance cool down;
- 2. Remove any dirt from inside the appliance.
- Dry the interior of the appliance with a soft cloth.
- 4. Leave the door open until the inside of the appliance has dried completely.

Removing racks/trays support frames


Removing the guide frames enables the sides to be cleaned more easily.

To remove the guide frames:

1. Unscrew the frame fastening pins:



2. Pull the frame towards the inside of the oven to free it from the fastening pins.



When cleaning is complete, repeat the above procedures to put the guide frames back in.

Cleaning the top section




WARNING


- The following operations must only be carried out when the oven is completely cold and switched off.
- Do not excessively flex the element during cleaning.

The appliance is equipped with a tilting heating element that allows for easy cleaning of the upper part of the oven cavity.

 Free the upper heating element by gently lifting it and rotating its retaining latch by 90 degrees.



Gently lower the heating element until it stops.



 When you have finished cleaning, place the heating element back in position and turn the retaining latch to lock it in place.


Cleaning the door

Removing the door


For easier cleaning it is recommended to remove the door and place it on a towel.

To remove the door proceed as follows:


 Open the door completely and insert two pins into the holes on the hinges indicated in the figure.



 Grasp the door on both sides with both hands, lift it forming an angle of around 30° and remove it.



 To reattach the door, insert the hinges into the slots on the oven, making sure that grooved sections A fit tightly in the slots.



4. Lower the door and once it is in place remove the pins from the holes in the hinges.

Cleaning the door glazing

The glass in the door should always be kept thoroughly clean. Use absorbent paper towels. If there are tough to clean spots, use a damp sponge and regular detergent.

Vapor Clean



WARNING



NOTES

 The Vapor Clean function is an assisted cleaning procedure which facilitates the removal of dirt. Thanks to this process, it is possible to clean the inside of the oven very easily. The dirt residues are softened by the heat and water vapor for easier removal afterwards.

Preliminary operations

Before starting the Vapor Clean function:

- Remove all accessories inside the oven cavity.
- Remove any food residue inside the appliance.
- Perform the Vapor Clean function only when the appliance is cold.
- Remove the temperature probe (where fitted).
- Remove the self-cleaning panels (where fitted).
- During the assisted cleaning cycle, wash the self-cleaning panels (where fitted), which were previously removed, separately in warm water and a small amount of detergent.
- Pour approx. 4 fl. oz. (120 cc) of water onto

the floor of the oven. Make sure it does not overflow out of the cavity.



 Spray a water and mild liquid detergent inside the oven using a spray nozzle. Direct the spray against the side walls, upwards, downwards and towards the deflector.



Close the door.

NOTES

 We recommend spraying approx. 20 times at the most.

Vapor Clean cycle setting



NOTES

- If the indoor temperature is higher than expected, the function is not activated. Let the appliance cool down before activating the function.
- The duration and temperature of the Vapor Clean function cannot be changed by the user.
- It is possible to set the delayed function ...

Touch the OTHER FUNCTIONS
 button on the "main menu" (in the main area





End of Vapor Clean

At the end of the Vapor Clean function, "Function ended" is shown on the display and a buzzer sounds briefly.



- the function.

 2. Proceed with reservoir draining as
- Proceed with reservoir draining as described above.
- 3. Open the door and wipe away the less stubborn dirt with a microfiber cloth.
- Use a non-scratch sponge with brass filaments on hard to remove deposits.
- 5. In case of grease residues use specific oven cleaning products.
- Remove any remaining water from the oven cavity.
- 7. Where fitted, reposition the self-cleaning panels and the rack/tray support frames.

For greater hygiene and to avoid foods taking on unpleasant odors:

- we recommend drying the inside of the oven with a fan-assisted function at 160°C for around 10 minutes.
- Where the self-cleaning panels are fitted, we recommend drying the oven cavity with a simultaneous catalytic cycle.

■ NOTES


- We recommend wearing rubber gloves for these operations.
- We recommend removing the door in order to make the manual cleaning of the parts that are difficult to reach easier.

Extraordinary maintenance


Replacing the oven light

WARNING

- Unplug the appliance.
- Wear protective gloves.
- 1. Remove all accessories inside the oven.
- 2. Remove the frame supports for racks/trays.
- Use a tool (e.g. a spoon) to remove the bulb cover.



4. Loosen and remove the light bulb.




■ NOTES

- Be careful not to scratch the enamel of the oven walls.
- 5. Replace the bulb with a similar one (40 W).



• Do not touch the halogen bulb with your fingers; cover them with an insulating cloth.

6. Reattach the cover. Ensure the molded part of the glass (A) is facing the door.



7. Press the cover firmly so that it adheres tightly to the light bulb holder.

Seal maintenance tips

The seal should be soft and elastic.

 To keep the seal clean, use a non-abrasive sponge and wash with lukewarm water.

What to do if...

The display is completely off:

- Check the mains power supply.
- Check if any circuit breakers upstream of the appliance supply line are in the "ON" position.

The appliance does not heat up:

 Check whether "Show Room (for showrooms only)" or "Demo Mode (for showrooms only)" has been set (for further details see "settings" section).

The controls do not respond:

 Check whether the "Controls lock" mode has been set (for further details see "settings" section).