


Setup Guide

Téléviseur
Televisor digital a color con pantalla de diodo orgánico
de emisión de luz (OLED)
Televizor



5-057-739-11(1)



EN	Setup Guide
FR	Manuel de configuration
ES	Guía de configuración
PT	Guia de Configuração

Sony Customer Support
U.S.A.:
<https://www.sony.com/tvsupport>
Canada:
<https://www.sony.ca/support>
U.S.A. Canada
1.800.222.SONY (7669) 1.877.899.SONY (7669)
Please Do Not Return the Product to the Store
Service à la clientèle Sony
Canada :
<https://www.sony.ca/support>
États-Unis :
<https://www.sony.com/tvsupport>
Canada États-Unis
1.877.899.SONY (7669) 1.800.222.SONY (7669)
Ne retournez pas le produit au magasin

Lea este manual antes de usar el producto
Centro de Asistencia de Sony
<https://esupport.sony.com/ES/LA/>
Llame al número telefónico que aparece en
su póliza de garantía.
Por favor no devuelva el producto a la tienda
donde adquirió el producto.

BRAVIA
K-77XR80 / 77XR80C / 65XR80
K-65XR80C / 55XR80 / 55XR80C

1

SB

CN

IM

65 55

SB

CN

M5L16

CD

*1

*1 *2

77

65

55

1.5 N·m/1,5 N·m
(15 kgf·cm)

2

3

*1

55

CC

77

65

CC

4

5

1

2

SB

M5L16

x 2

4

5

SB

M5L16

x 2


6

*1 Only for limited region/country/model. / Uniquement pour certaines régions/pays/modèles. / Solo para regiones/países/modelos limitados. / Exclusivo para regiões/países/modelos especificados.


*2 Refer Reference Guide. / Reportez-vous au Manuel de référence. / Consulte la Guía de referencia. / Consulte o manual de instruções.

© 2024 Sony Corporation


7




8






9




10




11




*3




*4



*5



*6



*7

