


# ASTI 30"

EAS430SS



	EAS430SS
<b>A</b>	3/8" (10 mm)
<b>B</b>	30" (76.2 cm) or 36" (91.4 cm)
<b>C</b>	26" (66.1 cm)
<b>D</b>	2" (5.1 cm) or 5" (12.7 cm)
<b>E</b>	10 <sup>3</sup> / <sub>4</sub> " (27.4 cm)
<b>F</b>	3/4" (19 mm)
<b>G</b>	11 <sup>7</sup> / <sub>8</sub> " (30.2 cm) or 17 <sup>7</sup> / <sub>8</sub> " (45.4 cm)
<b>H</b>	9 <sup>1</sup> / <sub>8</sub> " (23.1 cm)
<b>I</b>	13 <sup>5</sup> / <sub>8</sub> " (33.7 cm)

For gas and electric ranges installation: Mount this hood so that the bottom edge is at minimum 30"(76.2 cm) above the cooking surface.