LG REFRIGERATION

LRONC1404V ŠÜUÞÔFI FI Õ

Gl ÄÂÔ˘•ȼ{ ã æà|^ÁÔ[|˘{}ÄÜ^÷ã^¦æ{¦ẾÁÔ[˘}c^¦ÁÕ^]c@ỀFHḔÁ&˘È¢È

13.6 cu.ft. Capacity
Smart Inverter Compressor
Multi-Air Flow
Door Cooling+
Zero Clearance
SmartPull™ Handle
Reversible Door
Smart Diagnosis™
ENERGY STAR® Qualified

FHḔÁ&˘È¢ÉÁÔæ̧ æ&ã̃
Ô˘•ȼ{ ã æà|^Á&[}~ã̃˘¦ææ̧}
T˘|c@̈ÐãÁ̃[¸ÇⱯT DÄÙˆ•c^{
Ö[[¦ÁÔ[[|ã̃*É
Z^¦[ÁÔ|^æ̧æ̧&^
Ù{ æ̧ȼ˘||ÇⱯT DÁ́Pæ̧å|^
Ü^ç^¦•ã̃|^ÁÕ[[¦
V@̧ÛÇⱯT D
ÒÞÒÜÕˇÝẤÙVŒÜÇÜDÄ́˘ æ̧ã̃ã̃å

Ô@̧æ̧*^Áȩ́ æ̃^Á̧Ȩ́ÁÕ^ã̃^Á
Õ|æ̧•Á́¦ã̃*^

Ô[[˘¦ÁÔ^ã̃^ÁÕ̃|æ̧•
Œȩææ̧|æ̧à|^ÁÕ[[¦Áᶜæ̧}^Áᶜ&[}˘¦ÁÁÙã̃\ÁÕ|æ̧•ẾTã̃ȼÕ|æ̧•Ế
Õ|^^}ÁÜȩ̧æ̧à|^•̧•ÁÜc^¦ÊᶜÄ́ Üȩ̧æ̧à|^•̧•ÁÜc^¦ÊẾTáæᶜ^ÁÕ|æ̧&ʌ́Á
Ùȩ̧æ̧à|^•̧•ÁÜc^¦Áᶜ&ȩ̧åʌ́Áæ̧}^Á̧¦[å˘&̧{ÊᶜD

Eᶜᶜȩ̧åã̃}̧æ̧|A&[[˘¦̧•ʌ́Á̃ʌ́Õ[[¦ÁÜȩ̧æ̧}^|•Á̃ÁÔȩ̧æ̧à|æ̧à|^ʌ́Eᶜ&æ̧ʌ́|Á
Fḙ̀Ì ̀ḙ̀ŀ GᶜᶜĠĦ́À|̧ʌ́å^¦̧Ế¦[{ Á̃ŠṌÁÜæ̧ᶜ&̧ÁẤÁ̃^¦¦çã̃ʌ́ᶜ̧Á
Ç@̧Ù̃ʌ́[¦ȼ̧}̧ʌ́Á̧¦̧ʌ́¦[{ Á̃^æ̧]æ̧åDE

Œȩ̧åÁ́̃V@̧Û́Á[*[

CAPACITY

Refrigerator (cu.ft.)	13.6
Total Capacity (cu.ft.)	13.6

ENERGY

Energy Consumption (kWh/Year)	GFH
ENERGY STAR® Qualified	Yes

COOLING

Smart Inverter Compressor	Yes
Multi-Air Flow	Yes
No Frost	Yes
Door Cooling+	Yes

CONVENIENCE

Temperature Controls	Digital
Express Cool	Yes
Door Alarm	Yes
Sabbath Mode	Yes
Smart Diagnosis™	Yes

Œȩ̧åÁ́̃V@̧Û́Á̧å^¦̧Á́Û́{ æ̧ȼ̧Á
Öæ̧ȩ̧}̧•æ̃ÇⱯT D

REFRIGERATOR

No. of Shelves	Í
Shelf Construction	Spill Protector™ Tempered Glass
Wine Rack	Yes
Crisper Bins	1
Refrigerator Light	LED

REFRIGERATOR DOOR

No. of Bins	5
Door Bin Construction	1 Piece (Clear)
Reversible Door	Yes

MATERIALS AND FINISHES

Door Type	Flat
Reversible Door	Yes
Hidden Hinges	Yes
Zero Clearance	Smudge Ÿ^•
Handles	SmartPull

ŒÕ^æ̧|¸[Õ[[¦ÁÜæ̧}^|
Ô[[˘¦   Ó^ã̃^ÁÕ|æ̧•

DIMENSIONS/CLEARANCES/WEIGHTS

Depth with Handles	GÏ Ã Ð Ä
Depth without Handles	GÏ Ã
Depth without Door	GÌÃ Ð Ä
Depth (Total with Door Open)	I Ì ÃÐÄ
Height to Top of Case	Ï HÃÐ Ä
Height to Top of Door Hinge	Ï HÃÐ Ä
Width	GÌÃÐÐÄ
Installation Clearance	¦^˄¦Á̧æ̧•æ̧|æ̧æ̃}̧Á̧æ̃^
Weight (Unit/Carton)	FÍ Î |àæ̧ÆÐÀVÖÖ
Carton Dimensions (WxHxD)	VÖÖ

LIMITED WARRANTY

Parts & Labour	1 Year
Sealed System	7 Years
Inverter Linear Compressor	10 Years

UPC CODES

ŠÜUÞÔFI FI ÕÁ́Ô^ã̃^ÁÕ|æ̧•DᶜÆFJÍ FÍ I €̂Î FJÌ

Customizable Configuration

Allows you to design your space to suit your needs

1 Fridge or Freezer	1 Fridge & 1 Freezer	2 Fridges & 1 Freezer	2 Fridges & 2 Freezers

73.3"

23.5"

¦^}|æ̧&^¦Á&[[˘¦Á̧å̧æ̃@̧Áæ̃@̧¦ÁÁ́Ô^ã̃^ÁẾÁÜã̃\ÊᶜTã̃ȼ́ã̃&.

*Refrigerator includes brackets that can be used to secure multiple units together

Installing the products as pairs

(Contact a LG Electronics service center, After initial product installation, all services requested by the customer will be charged.)

Installation components

Before installing the freezer and refrigerator in pairs, prepare the following components.
The number of screws may vary according to the model.

1. Bracket frame A (1EA) 2. Bracket frame B (1EA) 3. Deco case (1EA) 4. Screw A (2EA) 5. Screw B (6EA) 6. Bracket frame C (1EA) 7. Cap Door (2EA)

How to install the product as part of a pair

1. Install the freezer and refrigerator side by side by referring to the basic installation sequence and reference dimensions below.
[Basic installation order]
• When installing 2 units: Freezer-Refrigerator
[Reference dimension]

	Dimension (mm)
A	minimum 50
B	50
C	11
D	110°
E	1643

2. If the appliance seems unsteady, or the doors do not close easily, adjust the appliance's tilt using the instructions below.
Turn the leveling leg clockwise to raise that side of the appliance or counterclockwise to lower it.

3. If the door of the appliance is not level, adjust the difference in the height of the appliance door.
• Open the door and use the spanner (1) to loosen the keeper nut by turning it to the left.
• Use the spanner (2) to adjust the height by turning the adjustment hinge pin to the left or to the right

4. Remove the No. (4) screw from the radiation grill in the back of the product. Align the No. (1) bracket frame in the hole in the product and reassemble it using the No. (4) screw.

5. Align the No. (6) bracket frame with the hole in the top of the product and assemble it using the No. (5) screw.

6. Remove the No. (5) screw from the bottom of the front of the product. Align the No. (2) bracket frame with the hole in the product and reassemble it using the No. (5) screw.

7. Insert the No. (4) deco cover between the tops of the products. Next, insert the No. (5) deco case between the products (deco cover) slowly, starting from the top, until it is fully fitted.

Top

Shape of the deco case

MBM63936335_Rev.01